

Postal Shipping Procedures

1. Bundle tubes together in groups of 1-5 tubes with a rubber band.
2. Wrap the bundle with absorbent paper towel or newspaper (enough to absorb all fluid if all tubes break).
3. Alternatively, styrofoam shipping containers which hold 5 tubes or green boxes which hold 40 tubes can be used (lab can supply these to you at no charge).
4. Place inside a leak proof Ziplock bag.
5. Pack the tubes or shipping containers in a box with enough bubble wrap or other packing material to avoid movement and seal the box.
6. Do not include ice packs.
7. Ship the samples to:

BioCheck
#6 – 320 WT Hill Blvd.
Lethbridge, AB
T1J 4W9

403-328-1844

